
neon

English Simple Manual



Turning the Power On and Off

- ■Turning the Power On
 - Press and hold for more than one second.
- ■Turning the Power Off
 - Press and hold for more than one second.

Checking Your Own Phone Number and E-mail Address

From the stand-by screen: press press press.

Making/Answering a Call

- Making a Call
 - From the stand-by screen: enter the phone number press .
- To end the call: press off.
- Answering a Call
 - Press g while the phone is ringing.

To adjust the earpiece volume during a call: press 📳 🕨 press 🔳 [OK].

Storing/Recalling an Entry in the Phone Book

Storing an Entry

Recalling an Entry

From the stand-by screen: press to display the Name Search screen ▶ press ♀ to select the name ▶ press ■ [選択] (Select) to display the entry's details screen.

Using the Camera (Movie Clips/Photos)

Recording a Movie Clip


From the stand-by screen: press and hold ● for more than one second press ■ [録画] (Record) to start recording press ■ [保存](Save) to save the movie.

To stop recording: press [■] [停止] (Stop) during recording.

Taking a Photo

From the stand-by screen: press ■ press ■ [撮影](Shoot) to take a photo press ■ [保存](Save) to save the photo.

Making an International Call





English Announcement Function

You can play Voice Mail Service operation instructions and answering messages in English.

From the stand-by screen: press ■ press -5- press -7- press -6- press ■ [発信](Call).

Other Handy Features

Setting the Manner Mode

From the stand-by screen: press and hold - for more than one second.

To cancel Manner mode: press and hold \Box for more than one second from the stand-by screen.

Setting the Voice Memo

From the stand-by screen: press and hold for more than one second.

To cancel the Voice Memo: press and hold [elear] for more than one second from the stand-by screen.

For inquiries, please contact

au Customer Service Center (General Information)

- If you are calling from an au mobile phone: 157 (toll free)